

TRX BATERIE PRO ACER 6600MAH



Cena celkem:

809 Kč

(bez DPH: 668 Kč)

Běžná cena:

890 Kč

Ušetříte:

81 Kč

Kód zboží:

BATRX1950

Part No.:

TRX-AS10D31 CXH

Záruka:

24 měsíců/6 měs. akku

Stav:

Nové zboží

Popis

TRX baterie pro Acer 6600 mAh

Kompatibilní baterie pro vybrané notebooky Acer . Disponuje ochranou proti hlubokému vybití, přebití a přehřátí. Provozní doba odpovídá originální baterii stejné kapacity.

ZÁKLADNÍ SPECIFIKACE

Kapacita: 6600 mAh

Napětí: 10,8 / 11,1 V

Rozměry: 270 × 52 × 40 mm

Hmotnost: 470 g

Technologie baterie: Li-Iontová

Nahrazuje baterie:

AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E, AS10D71, AS10D73, AS10D75, AS10D81, AS10G3E, BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129, BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008, BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130, LC.BTP0A.015, LC.BTP00.123, 31NR19/65-2, 31CR19/652, 31CR19/65-2, 31CR19/66-2, AK.006BT.075, AK.006BT.080

Pro notebooky:

ACER

Aspire AS5253, Aspire E1, Aspire E1-421, Aspire E1-431, Aspire E1-471, Aspire E1-471G, Aspire E1-521, Aspire E1-531, Aspire E1-571, Aspire V3, Aspire V3-471, Aspire V3-551, Aspire V3-551G, Aspire V3-571, Aspire V3-571G, Aspire V3-731, Aspire 4250, Aspire 4250G, Aspire 4250Z, Aspire 4251, Aspire 4251G, Aspire 4251Z, Aspire 4252, Aspire 4252G, Aspire 4252Z, Aspire 4253, Aspire 4253G, Aspire 4333, Aspire 4339, Aspire 4349, Aspire 4350, Aspire 4350G, Aspire 4352, Aspire 4551, Aspire 4551G, Aspire 4551P, Aspire 4552, Aspire 4552G, Aspire 4560, Aspire 4560G, Aspire 4733Z, Aspire 4738, Aspire 4738G, Aspire 4738Z, Aspire 4738ZG, Aspire 4739, Aspire 4739Z, Aspire 4741, Aspire 4741G, Aspire 4741Z, Aspire

4741ZG, Aspire 4743, Aspire 4743G, Aspire 4743Z, Aspire 4743ZG, Aspire 4749, Aspire 4749Z, Aspire 4750, Aspire 4750G, Aspire 4750Z, Aspire 4750ZG, Aspire 4752, Aspire 4752G, Aspire 4752Z, Aspire 4752ZG, Aspire 4755, Aspire 4755G, Aspire 4755ZG, Aspire 4771, Aspire 4771G, Aspire 4771Z, Aspire 5250, Aspire 5251, Aspire 5252, Aspire 5253, Aspire 5253G, Aspire 5333, Aspire 5336, Aspire 5342, Aspire 5349, Aspire 5350, Aspire 5551, Aspire 5551G, Aspire 5552, Aspire 5552G, Aspire 5560G, Aspire 5733, Aspire 5733Z, Aspire 5736, Aspire 5736G, Aspire 5736Z, Aspire 5736ZG, Aspire 5741, Aspire 5741G, Aspire 5741Z, Aspire 5741ZG, Aspire 5742, Aspire 5742G, Aspire 5742Z, Aspire 5742ZG, Aspire 5749, Aspire 5749Z, Aspire 5750, Aspire 5750G, Aspire 5750TG, Aspire 5750Z, Aspire 5750ZG, Aspire 5755, Aspire 5755G, Aspire 5755Z, Aspire 5755ZG, Aspire 7251, Aspire 7551, Aspire 7551G, Aspire 7551Z, Aspire 7551ZG, Aspire 7552G, Aspire 7552G-5107, Aspire 7552G-5488, Aspire 7552G-6061, Aspire 7560, Aspire 7560G, Aspire 7741, Aspire 7741G, Aspire 7741Z, Aspire 7741ZG, Aspire 7750, Aspire 7750G, Aspire 7750Z, Aspire 7750ZG, TravelMate P243, TravelMate P243-M, TravelMate P243-MG, TravelMate P253, TravelMate P253-E, TravelMate P253-M, TravelMate P253-MG, TravelMate P273-M, TravelMate P273-MG, TravelMate TM5740, TravelMate TM5742, TravelMate 4370, TravelMate 4740, TravelMate 4740G, TravelMate 4740Z, TravelMate 4740ZG, TravelMate 4750, TravelMate 4750G, TravelMate 4750Z, TravelMate 4750ZG, TravelMate 5335, TravelMate 5335G, TravelMate 5335Z, TravelMate 5340, TravelMate 5340G, TravelMate 5344, TravelMate 5360, TravelMate 5360G, TravelMate 5542, TravelMate 5542G, TravelMate 5735, TravelMate 5735G, TravelMate 5735Z, TravelMate 5735ZG, TravelMate 5740, TravelMate 5740G, TravelMate 5740Z, TravelMate 5740ZG, TravelMate 5742, TravelMate 5742G, TravelMate 5742Z, TravelMate 5742ZG, TravelMate 5744, TravelMate 5744G, TravelMate 5744Z, TravelMate 5760, TravelMate 5760G, TravelMate 6495, TravelMate 6495G, TravelMate 6495T, TravelMate 6495TG, TravelMate 6595, TravelMate 6595G, TravelMate 6595T, TravelMate 6595TG, TravelMate 7340, TravelMate 7740, TravelMate 7740G, TravelMate 7740Z, TravelMate 7740ZG, TravelMate 7750, TravelMate 7750G, TravelMate 7750Z, TravelMate 7750ZG, TravelMate 8472, TravelMate 8472 HF, TravelMate 8472G, TravelMate 8472G HF, TravelMate 8472T, TravelMate 8472T HF, TravelMate 8472TG, TravelMate 8472TG HF, TravelMate 8473, TravelMate 8473G, TravelMate 8473T, TravelMate 8473TG, TravelMate 8572, TravelMate 8572G, TravelMate 8572T, TravelMate 8572T HF, TravelMate 8572TG, TravelMate 8573, TravelMate 8573G, TravelMate 8573T, TravelMate 8573TG

EMACHINES

D440, D44,2 D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730

GATEWAY

NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53 serie, NV53A, NV53A serie, NV53A11u, NV55C, NV55C serie, NV59C, NV59C serie, NV73A, NV73A serie, NV79, NV79 serie, NV79C

PACKARD BELL

EasyNote LM81, EasyNote LM82, EasyNote LM83, EasyNote LM85, EasyNote LM86, EasyNote LM87, EasyNote LM94, EasyNote LM98, EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM01, EasyNote TM80, EasyNote TM81, EasyNote TM82, EasyNote TM83, EasyNote TM85, EasyNote TM86, EasyNote TM87, EasyNote TM89, EasyNote TM94, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44